

50G Junior & Superwash

How to Assemble Guide & Rubber Strips



Call 1-800-869-1800 or go online at wittekgolf.com to order!



Golf Supply Specialists

1. Make sure metal plates are securely screwed in as show below



****If replacing guide set on 50G Superwash, insert black rubber pad before starting Step 2****

2. Begin by putting guide set in washer as shown below (Orange dot = screw)

Back ↙

↘ Front (Water Tank)



3. Insert rubber strips & use drill to secure each strip using 2 screws on one side (Old holes may be used, if worn, route new ones)



4. Next, insert 2 screws, using a drill, onto the bottom/center of the strip to secure it to the tank (Old holes may be used, if worn, route new ones)



5. Finally, insert 2 more screws into the other side of the strip, in the same way as step 3, and cut any excess rubber that overlaps (Old holes may be used, if worn, route new ones)

